

Toyota FJ Cruiser Barrier net installation tips

To increase the usefulness of the Raingler net, we recommend replacing the plastic coat hangars at the top with a pair of the Toyota "Luggage Belt Striker Assembly" part number 5846035012 They typically cost about \$15 USD from the dealership.

First; cut a slot through the edge of the hook...



...very carefully!

You need to leave a portion of where it hinges intact for it to close back and stay locked, so BE CAREFUL!

Next, set the factory d-ring tab inside the hook, like so...



..and bolt it back up.



Carefully snap the clasp back in for the hook and voila! Instant toughness.



Point of interest. Because Toyota uses the same mold for both sides, your cargo ring will wind up on opposite sides of the hook. This isn't a problem because the d-ring sticks out far enough past it that it shouldn't matter.
See: Left side.



Right side...



Next, loosely install the upper portion of the net through the mounts you just installed as shown:

